TEXOMA FIVE DEPARTURE

TOP ALTITUDE:

ASSIGNED BY ATC

LOWGN

M

1100

WILL ROGERS

114.1 IRW := ·

Chan 88

DECKK

**TULSA** 

114.4 TUL ::-.

Chan 91

128.725 **GND CON** 132.65 306.2 **ALLIANCE TOWER** 

135.15 257.9

ROLLS

22 FEB

3 2024

ಠ

21 MAR 2024

RADAR and DME required.

**OKMULGEE** 

Chan 96

114.9 OKM = --

NOOGY

TEXOMA FIVE DEPARTURE (TEX5.FUZ) 25JAN24

TAKEOFF MINIMUMS Rwys 34L/R: Standard.

Rwy 16L: 300-21/4 or standard with minimum climb of 220'/NM to 1100, or alternatively, with standard takeoff minimums and a normal 200'/NM

climb gradient, takeoff must occur no later than 1900' prior to DER. Rwy 16R: 300-2½ or standard with

minimum climb of 225'/NM to 1100

or alternatively, with standard takeoff

minimums and a normal 200'/NM climb gradient, takeoff must occur no

later than 2000' prior to DER.

NOTE: Chart not to scale

FORT WORTH, TEXAS PEROT FLD/FORT WORTH ALLIANCE (AFW)

SA FUZ 25 M

2700

3600

R-256

**GRABE** 

RANGER

115.7 FUZ **□ = :** 

Chan 104

(CONTINUED ON FOLLOWING PAGE)

## TEXOMA FIVE DEPARTURE

SC-2,

22 FEB 2024

₫

21 MAR 2024

## DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 16R: Climb on heading 166° to 1100 before turning right.

When entering controlled airspace, fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitudé.

ARDMORE TRANSITION (TEX5.ADM): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC.

BLECO TRANSITION (TEX5.BLECO): From over FUZ VORTAC on FUZ R-360 to BLECO. DECKK TRANSITION (TEX5.DECKK): From over FUZ VORTAC on FUZ R-360 to NOOGY, then on IRW R-144 to DECKK.

EAKER TRANSITION (TEX5.EAKER): From over FUZ VORTAC on FUZ R-012 to EAKER. GRABE TRANSITION (TEX5.GRABE): From over FUZ VORTAC on FUZ R-012 to GRABE. OKMULGEE TRANSITION (TEX5.OKM): From over FUZ VORTAC on FUZ R-012 to EAKER, then on OKM R-196 to OKM VOR/DME.

ROLLS TRANSITION (TEX5.ROLLS): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC, then on ADM R-303 to ROLLS.

TULSA TRANSITION (TEX5.TUL): From over FUZ VORTAC on FUZ R-360 to ZEMMA. then on TUL R-201 to TUL VORTAC.

WILL ROGERS TRANSITION (TEX5.IRW): From over FUZ VORTAC on FUZ R-360 to ZEMMA, then on IRW R-145 to IRW VORTAC.

ZEMMA TRANSITION (TEX5.ZEMMA): From over FUZ VORTAC on FUZ R-360 to ZEMMA.

NOTE: BLECO Transition: ATC assigned.

NOTE: DECKK Transition: For all aircraft inbound to the Oklahoma City area. NOTE: EAKER Transition: For aircraft inbound to the Tulsa terminal area.

NOTE: GRABE Transition: ATC assigned.

NOTE: OKMULGEE Transition: For all aircraft overflying OKM VOR/DME proceeding

on J181 to BDF to destinations in the Chicago terminal area and north.

NOTE: TULSA Transition: For all aircraft overflying TUL VORTAC.

NOTE: WILL ROGERS Transition: For all aircraft overflying IRW VORTAC.